


PART NUMBER: **OUT-J-ST-01**

FIBER OPTIC SPLICE TRAY



Fiber optic splice tray is used for optic fiber management, storage and fiber optic fusion protection, easy for installation and movement.

The splice tray expands fiber splice capabilities as well as provides the splicing location for fiber optic cables. It can be put into the fiber distribution frame, fiber splice closure, optic terminal box etc.

FEATURES

- Easy to install
- Trays can be hinged one over another
- It is possible to terminate directly pigtails of 2mm
- Capacity: 12-fiber splice trays
- Each tray protects fiber independently
- Fiber to the home (FTTH) applications
- Operating temperature: -40°C - $+80^{\circ}\text{C}$
- Dimension: 155x104x13,5mm
- Material: ABS

